

51 37 261 Removing and installing/replacing window cavity cover strip for door window, rear left or right


Removing roller cover from luggage compartment,

Refer to Owner's handbook.

Fold rear-seat backrest forwards.


[Remove panel for roof pillar at rear \(C-pillar\).](#)

[Remove panel for roof pillar at rear \(D-pillar\).](#)



Remove screws (1 and 2).

Remove window cavity cover strip (3).



Installation:

Slide guides (1) into mounts of window frame.

Press guides (2) onto mount for window cavity cover strip.